



Change the way you think about time

KATANA

INSTRUCTION MANUAL



1. How to read the time

- The time is read like an analog watch.
- Hours are shown in the normal way by the Katana blade, minutes are also shown by the blades position between the hours.

A single 'Hour & Minute' hand



10:30

Hand is halfway between 10 & 11

2. How to set the time

- The time can be set like an analog watch.
- Pull the crown out and turn it clockwise or counter clockwise to set the time.
- When the time is set, push the crown back to its original position.



6 o'clock

Hand indicates 6 exactly

3. User information

I. Battery

- This watch uses a SR616SW replaceable watch battery.
- The battery is estimated to last for at least one year.

II. Warranty

- This watch is covered by a 1 year warranty. This warranty does not cover water damage, accidental damage, neglect or unauthorized repair.

III. Caution

- This watch is water resistant to 3ATM. Please do not use the watch in the shower, for swimming or for other water related activities.

SPECIFICATIONS

| | |
|------------------------|-----------------|
| Case Materials | Stainless Steel |
| Strap Materials | Stainless Steel |
| Case Dimensions | 38 x 44 x 7 mm |
| Finish | Polished |
| Maximum Fit Wrist Size | 210mm (approx.) |
| Weight | 115g |
| Display | Analogue |
| Batteries | SR616SW |
| Water Resistance | 3ATM |