





www.click-watch.com



How to see time (AM)  
Press button A




How to see time (PM)  
Press button A




How to see date  
Press button A twice





How to set time




Press and hold button B for about 2 seconds, it will go to SET time mode. (the hour LED light will be blinking) Press button A to increase the hour. (one LED is am, two LED is pm) Press button B to confirm and go to next setting.




How to set time




How to set time




3:17am




How to set date




24 Dec




How to set date




24 Dec




How to set date



24 Dec




How to set animation



ON OFF

The animation LED will be blinking. Press button A to turn on/off the animation. Press button B to confirm and go to next setting.

How to set animation



The animation selection LED will be blinking. Press button A to select the animation. (1-5) Press button B to confirm and exit the setting mode. If animation mode is on, the animation will be appeared every 1/2 hour between 7:00pm-12:00 midnight.