


# KAIIDOKU

## INSTRUCTION MANUAL



Change the way you think about time



# 1. How to read the time

- This watch uses an LCD “always on” display to show the time.
- You can illuminate the display at night time for a short time with the EL backlight by pressing button A.
- The current time is indicated by the blinking words.

Hours: 1-12



Minutes: groups of 10



Minutes: 1- 9



Other indicators:

AM, PM, Date, Alarm on, Alarm setting



Example 1



4:25 PM (all words are lit except the words that display the current time which blink.)

Example 2



7:04 AM Alarm on (all words are lit except the words that display the current time which blink.)

## 2. How to set the time and date

- Press and hold button B for 3 seconds to enter setting mode.

\*Note after 7 seconds of inactivity setting mode will deactivate

### I. Setting the hour

- The hour blocks will flash when you are in hour setting mode.
- Press button A to increase the hour as required.
- Hold button A to increase the hours more quickly.
- The AM or PM icon will blink to indicate that you are setting the time in AM or PM.
- Press button B to confirm and move to the minutes.

### II. Setting the minutes

- The minute blocks will flash when you are in minute setting mode.
- Press button A to increase the minutes as required.
- Hold button A to increase the minutes more quickly.
- Press button B to confirm and move to date setting mode.

Example:



Time setting mode (minute setting) 11:20 AM

### III. Setting the month

- The D icon will be lit to indicate that you are in date setting mode.
- The month blocks will flash when you are in month setting mode.
- Press button A to increase the month as required.
- Hold button A to increase the months more quickly.
- Press button B to confirm and move to the date.

Example:



Date setting mode (month setting) Five = May

### IV. Setting the date

- The date blocks will flash when you are in date setting mode.
- Press button A to increase the date as required.
- Hold button A to increase the date more quickly.
- Press button B to confirm and exit setting mode.

### 3. How to set the alarm

- Press and hold buttons A and B for 3 seconds to enter alarm setting mode.
- The alarm setting icon (AS) indicates that you are in alarm setting mode.

\*Note after 7 seconds of inactivity setting mode will deactivate

#### I. Setting the alarm hour

- The alarm time will be displayed and the hour will be flashing.
- Press button A to increase the hour as required.
- Hold button A to increase the hours more quickly.
- Press button B to confirm and move to the minutes.

Example:



Alarm setting mode (hour setting) 8:00 AM

#### II. Setting the alarm minutes

- The alarm time will be displayed with the minutes flashing and the alarm setting icon on.
- Press button A to increase the minutes as required.
- Hold button A to increase the minutes more quickly.
- Press button B to confirm and move to the alarm on/off setting.

#### III. Turning the alarm on or off

- The alarm time will be displayed.
- Press button A to turn the alarm on or off.
- The alarm on (A) icon indicates that the alarm is on.
- Press button B to confirm and exit alarm setting mode.

Example:



Alarm setting mode (on/off setting) 8:15 AM

## 4. User information

### I. Battery

- This watch uses a CR2016 replaceable watch battery.
- Battery lifetime will vary depending on use, but is estimated to last for at least one year.
- To maximize battery life you should limit use of the EL backlight.

### II. Warranty

- This watch is covered by a 1 year manufacturers' warranty. This warranty does not cover water damage, accidental damage, neglect or unauthorized repair.

### III. Caution

- This watch has limited water resistance. Please do not use the watch in the shower, for swimming or for other water related activities.

## SPECIFICATIONS

Case Materials	Stainless Steel
Strap Materials	Wood
Case Dimensions	47 x 35 x 9 mm
Finish	Brushed / Clear Coating
Maximum Fit Wrist Size	210mm (approx.)
Weight	72g
Display	LCD with EL backlight
Battery	CR2016